



BUTTON

Normally Open SW
LED +
switch GND
LED - / GND

4pin

1 GPIO0
2 GPIO1
3 GROUND
4 GROUND

GROUND

GPIO0
GPIO1

CONN_GPIO

1
2
3
4
5
6